



Canon EOS Rebel T4i Rubber Grips Replacement

This particular camera has three rubber grips, and with this guide users can replace the grips that have become worn-down or over-used.

Written By: Brooke Patterson



INTRODUCTION

In this guide, users can replace the rubber grips.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Removing the Rubber Grips



- Use the spudger to pry at the loose edges of the rubber grip.
- Continue to pull upward until the rubber grip is completely off.
- Repeat the first step to remove any, or all, grips you want to replace.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 12:18:50 AM.